




# COPERCHI LIDS TAPAS

Coperchio chiuso



Closed lid



Tapa cerrada


COD. CODE CÓD.	D (mm)	F (mm)	H (mm)	H1 (mm)
<b>C00 001</b>	137	127	30	21

## ANELLI PER COPERCHI LID RINGS AROS PARA TAPAS


Anello filettato per superfici piane





Threaded ring for flat surfaces



Aro roscado para superficies planas

COD. CODE CÓD.	D (mm)	Ø (mm) (inches)	B (mm)	C (mm)	L (mm)	 COD. / CODE / CÓD
<b>350 401</b>	159	120 4.7	125	112	17	<b>300 304</b>




COD. CODE CÓD.	D (mm)	F (mm) (inches)	B (mm)	C (mm)	L (mm)	 COD. / CODE / CÓD
<b>350 2420</b>	255	210 8.2	215	192	38	300 110 300 116 300 315
<b>350 2440</b>	360	313 12.3	320	290	38	300 120 300 330
<b>350 2460</b>	462	410 16.1	415	382	35	300 126 300 130 300 134
<b>350 480</b>	620	567 22.3	575	540	41	---


Anello filettato fissaggio laterale



Threaded ring with side connection




Aro roscado fijación lateral

COD. CODE CÓD.	D (mm)	F (mm) (inches)	B (mm)	C (mm)	L (mm)	V (mm)	 COD. / CODE / CÓD
<b>350 2520</b>	255	210 8.2	215	192	38	230	300 110 300 116 300 315
<b>350 2540</b>	360	313 12.3	320	290	38	335	300 120 300 330
<b>350 2560</b>	462	410 16.1	415	382	35	430	300 126 300 130 300 134

Guarnizioni di tenuta tra serbatoio e anello

Sealing gaskets between tank and ring

Juntas de sellado entre tanque y aro




COD. CODE CÓD.	Per anelli For ring Para aros
<b>350 401.020</b>	<b>350 401</b>
<b>350 420.020</b>	<b>350 2420 350 2520</b>
<b>350 440.020</b>	<b>350 2440 350 2540</b>
<b>350 460.020</b>	<b>350 2460 350 2560</b>
<b>350 480.020</b>	<b>350 480</b>


**Anello filettato per superfici piane con dop-  
pia guarnizione**





**Threaded ring for flat surfaces with  
double gasket**



**Aro roscado para superficies planas con  
doble junta**

COD. CODE CÓD.	D	F		B	C	L	 COD. / CODE / CÓD
	(mm)	(mm)	(inches)	(mm)	(mm)	(mm)	
<b>350 620</b>	255	210	8.2	215	192	38	300 110 300 116 300 315
<b>350 640</b>	360	313	12.3	320	290	38	300 120 300 330
<b>350 660</b>	462	410	16.1	415	382	35	300 126 300 130 300 134
<b>350 680</b>	620	567	22.3	575	540	41	---

Ricambi  
Spare parts  
Repuestos


D (mm)	Guarnizione Gasket Junta	Anello Ring Aro
255		
255	<b>350 620.020</b>	<b>350 2420</b>
355	<b>350 640.020</b>	<b>350 640.010</b>
460	<b>350 660.020</b>	<b>350 660.010</b>
620	<b>350 680.020</b>	<b>350 680.010</b>


**COPERCHI IN GOMMA  
RUBBER LIDS  
TAPAS DE GOMA**

**Coperchio in gomma con valvola di aspirazione**

**Rubber lids with suction valve**

**Tapas de goma con válvula de aspiración**



COD. CODE CÓD.	D1	D	H	 COD. / CODE / CÓD
	(mm)	(mm)	(mm)	
<b>352 420</b>	265	240	15	300 112 300 118 300 212 300 320
<b>352 440</b>	370	360	15	300 120 300 330
<b>352 460</b>	450	430	22	300 128 300 132 300 136

